



www.bdsensors.com

BA\_XMD\_E\_SRO

**Headquarter Eastern Europe**BD SENSORS s.r.o.  
Hradištská 817  
CZ - 687 08 Buchlovice  
Czech RepublicTel.: +420 572 411 011  
Fax: +420 572 411 497**Headquarter Western Europe / International**BD SENSORS GmbH  
BD-Sensors-Str. 1  
D - 95199 Thierstein  
GermanyTel.: +49 (0) 92 53 / 98 11-0  
Fax: +49 (0) 92 53 / 98 11-11**further agencies in:****EUROPE**

- Belgium
- Denmark
- Finland
- France
- Great Britain
- Greece
- Italy
- Lithuania
- Luxemburg
- Netherlands
- Norway
- Poland
- Portugal

- Romania
- Sweden
- Switzerland
- Slovakia
- Spain
- Turkey
- UK
- Ukraine

**AFRICA**

- Egypt
- South Africa

**ASIA**

- India
- Iran
- Israel
- Japan
- Kazakhstan
- Malaysia
- Singapore
- Taiwan
- Thailand
- Vietnam

**AUSTRALIA**

Adhere to the safety notes and operating instructions which are given in the operating manual. Additionally applicable regulations regarding occupational safety, accident prevention as well as national installation standards and engineering rules must be complied with!

This operating manual is part of the device, must be kept nearest its location, always accessible to all employees.

This operating manual is copyrighted. The contents of this operating manual reflect the version available at the time of printing. It has been issued to our best knowledge. However, errors may have occurred. BD SENSORS is not liable for any incorrect statements and their effects.

– Technical modifications reserved –

**1.2 Symbols used**

- DANGER!** – dangerous situation, which may result in death or serious injuries
- WARNING!** – potentially dangerous situation, which may result in death or serious injuries
- CAUTION!** – potentially dangerous situation, which may result in minor injuries
- CAUTION!** – potentially dangerous situation, which may result in physical damage
- NOTE** – tips and information to ensure a failure free operation

**1.3 Target group**

**WARNING!** To avoid operator hazards and damages of the device, the following instructions have to be worked out by qualified technical personnel.

**1.4 Limitation of liability**

By non-observance of the operating manual, inappropriate use, modification or damage, no liability is assumed and warranty claims will be excluded.

**1.5 Intended use**

- The **Differential Pressure Transmitter XMD** has been especially designed for the process industry and can be used for level measurement of closed, pressurized tanks, pump or filter controlling, etc. The transmitter is as a standard equipped with HART®-communication and the parameterisation can be done via PC, HART®-communicator, etc.
- It is the operator's responsibility to check and verify the suitability of the device for the intended application. In addition it has to be ensured, that the medium is compatible with the media wetted parts. If any doubts remain, please contact our sales department in order to ensure proper usage. BD SENSORS is not liable for any incorrect selections and their effects!
- The technical data listed in the current data sheet are engaging and must be complied with. If the data sheet is not available, please order or download it from our homepage. (<http://www.bdsensors.com/products/download/datasheets>)

**WARNING!** Danger through improper usage!


**1.6 Package contents**

Please verify that all listed parts are included in the delivery and check for consistency specified in your order:

- differential pressure transmitter
- protective cap
- this operating manual

**2. Product identification**

The device can be identified by its manufacturing labels. It provides the most important data. By the ordering code the product can be clearly identified.



**!** The manufacturing labels must not be removed from the device!

**3. Mechanical installation****3.1 Mounting and safety instructions**

- WARNING!** Install the device only when depressurized and currentless!
- WARNING!** This device may only be installed by qualified technical personnel who has read and understood the operating manual!
- !** Handle this high-sensitive electronic precision measuring device with care, both in packed and unpacked condition!

**1. General information****1.1 Information on the operating manual**

This operating manual contains important information on proper usage of the device. Read this operating manual carefully before installing and starting up the pressure measuring device.

**!** There are no modifications/changes to be made on the device.

**!** Do not throw the package/device!

**!** To avoid damaging the diaphragm, remove packaging and protective cap directly before starting assembly. The delivered protective cap has to be stored!

**!** Place the protective cap on the pressure port again immediately after disassembling.

**!** Handle the unprotected diaphragm very carefully - it is very sensitive and may be easily damaged.

**!** Do not use any force when installing the device to prevent damage of the device and the plant!

**!** For installations outdoor and in damp areas following these instructions:

- To prevent moisture admission in the plug the device should be installed electrically after mounting, at once. Otherwise a moisture admission has to be blocked e.g. by using a suitable protection cap. (The ingress protection in the data sheet is valid for the connected device.)
- Choose an assembly position, which allows the flow-off of splashed water and condensation. Avoid permanent fluid at sealing surfaces!
- When using a device with cable outlet, turn the outgoing cable downwards. If the cable has to be turned upwards, then point it downward so the moisture can drain.

- Install the device in such a way that it is protected from direct solar irradiation. Direct solar irradiation can lead to the permissible operating temperature being overstepped in the worst case.

**NOTE** When installing the device to the pressurized system, the operator has to ensure the correct sealing.

**NOTE** Check the intended resp. delivered seal for compatibility with the medium. If there is no compatibility, take a suitable seal.

**NOTE** Take note that no assembly stress occurs at the pressure port, since this may cause a shifting of the characteristic curve. This is especially important for very small pressure ranges as well as for devices with a pressure port made of plastic.

**NOTE** In hydraulic systems, position the device in such a way that the pressure port points upward (ventilation).

**NOTE** Provide a cooling line when using the device in steam piping.

**3.2 General installation steps**

- Carefully remove the pressure measuring device from the package and dispose of the package properly.
- Go ahead as detailed in the specific instructions below.

**3.3 Installation steps for NPT connections**

- Use a suitable seal, corresponding to the medium and the pressure input (e. g. a PTFE-strip).
- Screw the device into the corresponding thread by hand.
- Tighten it with a wrench (for 1/2" NPT: approx. 70 Nm).

**3.4 Positioning of the display and operating module**

The display and operating module is continuously rotatable so that clear readability is guaranteed even in unusual installation positions. To change the position go ahead as follows:

- Screw off the metal cap by hand.
- Turn the display and operating module carefully into the desired position by hand. The module is equipped with a rotational limiter.
- Before screwing on the cap again, the o-ring and sealing surfaces of the housing have to be checked for damage and if necessary have to be changed!
- Afterwards screw the metal cap on by hand and make sure that the housing is firmly locked again.

**WARNING!** It is prohibited to open and configure the devices in the presence of explosion hazards. Therefore it is recommended to position the display and operating module together with the mechanical installation.

**!** Pay attention that no moisture can enter the device. Moreover, the seals and the sealing surfaces should not get dirty, as this may cause a reduction of the degree of protection depending on the case of application or place of installation. This can lead to a breakdown of the devices or to irreparable damages on the device.

**4. HART® communication**

**DANGER!** It is prohibited to interrupt the intrinsically safe circuit in the presence of explosion hazards in order to loop in a HART® communication interface (HART®-communicator or HART®-modem).

The analogue output signal is overridden by an additional signal according to the HART®-specification. The device can be configured via a HART®-communication device. Therefore we suggest our programming kit CIS 150 (available as accessory).

To ensure a trouble-free operation the following requirements should be fulfilled:

maximal cable length between device and power supply:

$$L_{\max} = \frac{65 \cdot 10^4}{R_v \cdot C_v} - \frac{40 \cdot 10^3}{C_v}$$

whereas  $L_{\max}$ : maximum length of cable in [m]  
 $R_v$ : resistance of the cable together with the load resistance in [ $\Omega$ ]  
 $C_v$ : capacity of the cable in [pF/m]

resistance R:

$$R = \frac{U - 12}{0,024} \Omega$$

whereas U: power supply in [Voc]

The resistance must be at least 240  $\Omega$ .

**5. Electrical Installation**

**WARNING!** Install the device in currentless environments only!

**WARNING!** Install the connection for devices equipped with terminal clamps so that the separating spaces comply with the standard and the connecting lines cannot be loosened.

**!** By devices with pressure flameproof enclosure a cable gland M20x1.5 with the name HSK-M-Ex-d is prescribed. This is already premounted.

**DANGER!** Danger of explosion when surpassing the maximum supply of 28 Voc!

**NOTE** – The cap for the connection clamps and display can be opened only if a locking protection, headless screw with inside hexagonal, remove became. The screw is on the right side below the cap. After attach of the cap for display and for the connection clamps, the locking protection must be screwed again purely. Besides, the lubrication of the thread ways is not necessary.

**NOTE** - The cable gland by devices with flameproof enclosure is suitable only for the firm transfer!


Establish the electrical connection of the device according to the technical data shown on the manufacturing label, the following table and the wiring diagram.

**Pin configuration:**

Electrical connections	Terminal clamps in clamping chamber with cable gland M 20 x 1,5 (for cable Ø 5 up to 14 mm)
Supply +	+
Supply -	-
Test COM / Test -	TEST+
COM	COM/TEST-
Shield	COM

**Wiring diagram:**

2-wire system (current) HART®



**!** For the installation of a device with cable outlet following bending radii have to be complied with:

cable without ventilation tube:

static installation : 8-fold cable diameter  
dynamic application: 12-fold cable diameter

cable with ventilation tube:

static installation : 10-fold cable diameter  
dynamic application: 20-fold cable diameter

**!** Prevent the damage or removal of the PTFE filter which is fixed over the end of the air tube on devices with cable outlet and integrated air tube.

**!** To install a device with terminal clamps, the cap has to be screwed off. If the device is equipped with a display and operating module, this has to be pulled out carefully. Put it as long as installing the device non-tensioned next to the housing. Next insert it again carefully and ensure that the cords are not turned or squeezed. Before screwing on the cap again, the o-ring and sealing surfaces of the housing have to be checked for damage and if necessary to be changed! Afterwards screw the metal cap on by hand and make sure that the field housing is firmly locked again.

**!** For a clear identification, the intrinsically safe cables are marked with light blue shrink tubing (over the cable insulation). If the cable has to be modified (e. g. shortened) and the marking at the cable end has been lost in the process, it must be restored (for example, by marking it again with light blue shrink tubing or an appropriate identification label).

**NOTE** For the electrical connection a shielded and twisted multicore cable has to be used.

**6. Initial start-up**

**WARNING!** Before start-up, the user has to check for proper installation and for any visible defects.

**WARNING!** The device can be started and operated by authorized personnel only, who have read and understood the operating manual!

**WARNING!** The device has to be used within the technical specifications, only (compare the data in the data sheet and the EC type-examination certificate)!


**7. Operation****7.1 Display- and operating modul**

Fig. 4 touch pad

A bargraph is shown in the display, indicating the current pressure input as percentage of the specified pressure range. The indication of the measured value as well as the configuration of the individual parameters occurs through a menu via the display. The individual functions can be set with the help of three miniature push buttons located under the metal cap. For XMP is additionally the possibility given to operate via three push buttons (accessible from above). Therefore the metal plate (on the top side of the device), has to be folded backwards after loosening the right screw. The definition of the three buttons is: **▼**, **OK**, **▲** (starting at the left side).

The menu system is a closed system allowing you to scroll both forward and backward through the individual set-up menus to navigate to the desired setting item. All settings are permanently stored in a Flash EPROM and therefore available even after disconnecting from the supply voltage.

**WARNING!** It is prohibited to open and configure the devices in the presence of explosion hazards. After configuration it must be ensured that the device is completely closed again outside the explosion hazard area.

**!** Pay attention that no moisture can enter the device during configuration. Moreover, the seals and the sealing surfaces should not get dirty, as this may cause a reduction of the degree of protection depending on the case of application or place of installation. This can lead to a breakdown of the device or to irreparable damages on the device. Right after configuration, the metal cap has to be screwed on again.

**7.2 Structure of the menu system**

See arranged supplementary sheet (supplementary sheet / structure of the menu system). This supplementary sheet should only be used with this operating manual.

**7.3 Menu list**

- **▲-button:** with this button you move forward in the menu system or increase the displayed value; it will also lead you to the operating mode (beginning with menu item "1 DISPLAY")
- **▼-button:** with this button you move back in the menu system or decrease the displayed value; it will also lead you to the operating mode (beginning with menu item "5 SERVICE")
- **OK-button:** with this button menu items and set values have to be confirmed

**execution of configuration:**

- set the desired menu item by pushing the **▲**- or **▼**-button
- activate the set menu item by pushing the **OK**-button
- set the desired value or select one of the offered settings by using the **▲**- or **▼**-button
- store/confirm the set value/selected setting and exit the menu by pushing the **OK**-button.

☞ If a parameter is configurable by a value, each digit may be configured separately. That means after activating such a menu item (e. g. "2.3.1 OFFSET") by pushing the OK-button, the first digit of the currently set value will start to blink. Now scroll up or down to the desired digit via the ▼- or ▲-button and confirm it with the OK-button. After that, the next digit will start to blink. Configure it in the same way. In the menu items "2.3.1 OFFSET" and "2.3.2 FINALVAL", the decimal point will then start to blink and it is also possible to change its position by using the ▼- or ▲-button. By confirming the position with the OK-button, the total value will be stored if permissible. If the value is out of range, an error message (e. g. Error 03) will appear in the display and the set value will **not** be stored. If you intend to set a negative value, the first digit has to be configured with the ▼-button.

<b>1 DISPLAY</b>	<b>Display</b>
<b>1.1 P<sub>MAX</sub></b>	<b>Maximum pressure display (high pressure)</b> The maximum pressure applied during measuring is shown in the display.
<b>1.2 P<sub>MIN</sub></b>	<b>Minimum pressure display (low pressure)</b> The minimum pressure applied during measuring is shown in the display.
<b>1.3 T<sub>MAX</sub></b>	<b>Maximum temperature display (high temperature)</b> The minimum temperature during measuring is shown in the display.
<b>1.4 T<sub>MIN</sub></b>	<b>Minimum pressure display (high pressure)</b> The maximum pressure applied during measuring is shown in the display.
<b>1.5 CLEAR</b>	Use to clear the values 1.1-1.4 (P <sub>max</sub> , P <sub>min</sub> , T <sub>max</sub> , T <sub>min</sub> )
<b>1.6 INFO</b>	<b>Setting of the display</b> meaning of the permissible numbers: "1": 1. line: measured pressure 2. line: set pressure unit "2": 1. line: output signal 2. line: mA "3": 1. line: measured temperature 2. line: °C "4": 1. line: measured pressure 2. line: changes between set pressure unit / output signal in mA "5": 1. line: measured pressure 2. line: changes between set pressure unit / measured temperature in °C "6": 1. line: measured pressure 2. line: changes between set pressure unit / output signal in mA / measured temperature in °C
<b>2 CALIB</b>	<b>Calibration</b>
<b>2.1 ZERO</b>	<b>Offset correction</b> By choosing the submenu 2.1 with the OK-button, „CONFIRM“ appears in the display. By pushing the OK-button for at least 2 seconds, the correction is carried out and „CONFIRM“ disappears in the display.
<b>2.2 CAL REF</b>	<b>Calibration reference</b>
<b>2.2.1 OFFSET</b>	<b>Offset calibration</b> After feeding and adoption of reference value, choose the submenu 2.2.1 with the OK-button, „CONFIRM“ appears in the display. By pushing the OK-button for at least 2 seconds, the calibration is carried out and „CONFIRM“ disappears in the display.
<b>2.2.2 FINALVAL</b>	<b>Final value calibration</b> After feeding and adoption of reference value, choose the submenu 2.2.2 with the OK-button, „CONFIRM“ appears in the display. By pushing the OK-button for at least 2 seconds, the calibration is carried out and „CONFIRM“ disappears in the display.
<b>2.3 ADJUST</b>	<b>Adjust</b>
<b>2.3.1 OFFSET</b>	<b>Setting of the initial value of the measuring range</b> With button ▲ and ▼ you can set an initial value of measuring range. The value of new range is max. 100:1 (or 30:1, depending on the range).
<b>2.3.2 FINALVAL</b>	<b>Setting of the terminal value of the measuring range</b> With button ▲ and ▼ you can a terminal value of measuring range. The value of new range is max. 100:1 (or 30:1, depending on the range).
<b>2.3.3 Z-CORR</b>	<b>Resetting the offset</b> By choosing the submenu 2.3.3 with the OK-button, „CONFIRM“ appears in the display. By pushing the OK-button for at least 2 seconds, the resetting is carried out and „CONFIRM“ disappears in the display.
<b>3 SIGNAL</b>	<b>Signal</b>
<b>3.1 FUNKTION</b>	Function selection e.g. "LINEAR" (linear function)
<b>3.2 DENSITY</b>	Input the density [kg/m <sup>3</sup> ]. The unit will be changed to [mFs]
<b>3.3 DAMP</b>	<b>Setting of the damping</b> permissible range: from 0 up to 100 sec
<b>3.4 SIMULAT</b>	Free input of output signal [mA] for simulation of plant conditions (from 3,8 ... 21,6 mA)
<b>4 SETTINGS</b>	Settings
<b>4.1 DISPLAY</b>	Extension of display
<b>4.1.1 UNIT P</b>	<b>Setting of the pressure unit</b> permissible units: bar, mbar, g/cm <sup>2</sup> , kg/cm <sup>2</sup> , Pa, kPa, Torr, atm, mmWS (mm H2O), mmHg, PSI, FIH <sub>2</sub> O FIH <sub>2</sub> O- feat H <sub>2</sub> O 20°C ☞ a conversation of all pressure related parameters is carried out automatically
<b>4.1.2 UNIT T</b>	<b>Setting of the temperature unit</b> Switching between the unit [°C], [°F] and [K]
<b>4.2 HART-ID</b>	<b>HART-ID (only for HART®- devices with multidrop-mode to adjust)</b> HART-ID (only with HART® - to put to devices in the multi drop mode) Put the desired ID No. (between "0 and 15") and confirm this with the OK-button. A configuration of this number is only necessary if you liked to pursue the device in the multi drop mode (connection of several HART® devices). If the ID No. on "0" is put, the multi drop mode is deactivated and the pressure transmitter works in the analogous mode.
<b>4.3 USER-L</b>	<b>Configuration of the access protection</b> For security reasons, it is necessary to enter the password before configuring the access protection. Confirm it with the OK-button. The default setting for the password is "0000". meaning of the permissible numbers: "0": the complete menu system is unlocked "1": following menus are unlocked: 1 DISPLAY, 3 SIGNAL, 4.3 USER-L "2": following menus are unlocked: 1 DISPLAY, 4.3 USER-L
<b>4.4 PASSW</b>	<b>Configuration of the password</b> For security reasons, it is necessary to enter the current password before the configuration of the new one. Confirm with the OK-button. The default setting for the password is "0000". Then set the new password and confirm with the OK-button.
<b>4.5 LANGUAGE</b>	Choosing of user language [DE] or [EN]
<b>5 SERVICE</b>	<b>Service</b>
<b>5.1 FACTORY</b>	To restore to factory settings
<b>5.2 ERR CURR</b>	<b>Error current limits</b> Setting of the error current limit value: 21,6 mA or 3,8 mA
<b>5.3 TYPE</b>	<b>Displaying of the type of device</b>
<b>5.4 SER-NO</b>	<b>Displaying of the serial number</b>
<b>5.5 VERS</b>	<b>Displaying of the program version</b>

A When several HART ® devices are used on the same wire, the short address of each device is entered here.

If the address is 0, only one device is on the line, and the current output is 4...20 mA.

If the address is 1...15, several devices may be connected to the network, and the output current of the devices is 4 mA. If multiple devices are connected to the same network, each device must have a unique address, and the address may not be 0.

FACTORY DEFAULT: 0

## 8. Error handling

### 8.1 Error messages

<b>PASSED PARAMETER TOO SMALL</b>	passed parameter value is too small
<b>PASSED PARAMETER TOO LARGE</b>	passed parameter value is too large
<b>LOOP CURRENT NOT ACTIVE</b>	loop current is not active (HART ID > 0, device work in mode Multidrop)
<b>APPLIED PROCESS TOO LOW</b>	applied process is too low
<b>APPLIED PROCESS TOO HIGH</b>	applied process is too high
<b>LOWER RANGE VALUE TOO HIGH</b>	lower range value (OFFSET) is too high
<b>LOWER RANGE VALUE TOO LOW</b>	lower range value (OFFSET) is too low
<b>UPPER RANGE VALUE TOO HIGH</b>	upper range value (FINALVAL) is too high
<b>UPPER RANGE VALUE TOO LOW</b>	upper range value (FINALVAL) is too low
<b>SPAN TOO SMALL</b>	span too small

### 9.2. More errors and possible corrections

Malfunction	Possible cause	Error detection / corrective
display does not work	falsely connected	inspect the connections
	line break	inspect all connecting lines of the device (including the connector plugs)
	defective energy supply	inspect the power supply and the applied supply voltage at the transmitter
no output signal	wrong connected	inspect the connection
	line break	inspect all line connections necessary to supply the device (including the connector plugs)
	defective amperemeter (signal input)	inspect the amperemeter (fine-wire fuse) or the analogue input of the PLC
analogue output signal too low	load resistance too high	verify the value of the load resistance
	supply voltage too low	verify the output voltage of the power supply
	defective energy supply	inspect the power supply and the applied supply voltage at the device
small shift of output signal	diaphragm is highly contaminated	careful cleaning with non-aggressive cleaning solution and a soft brush or sponge; incorrect cleaning can cause irreparable damages on diaphragm or seals
	diaphragm is calcified or coated with deposit	if possible it is recommended to send the device to BD SENSORS for decalcification or cleaning
large shift of output signal	diaphragm is damaged (caused by overpressure or manually)	check the diaphragm; if it is damaged, please send the device to BD SENSORS for repair
measured value (display and analogue output) deviates from the nominal value	high pressure / pressure peaks	a recalibrated or replaced of the pressure port by BD SENSORS is necessary
	mechanical damage to diaphragm	
constant output signal at 4 mA	wrong ID-number	ensure in the menu item "ID" that the set value for the ID-number is "0000"

If you detect an error, please try to eliminate it by using this table or send the device to our service address for repair.

⚠ DANGER! Working on supplied (active) parts, except for intrinsically safe circuits, is principally prohibited during an explosion hazard. Additionally, the operator is obligated to observe the information concerning operation and maintenance work on the warning signs possibly affixed to the device.

! Improper action and opening can damage the device. Therefore repairs on the device may only be executed by the manufacturer!

### 9. Placing out of service

⚠ WARNING! Disassemble the device only in current and pressure less condition! Check before disassembly, if it is necessary to drained off the media before dismantling!

⚠ WARNING! Depending on the medium, it may cause danger for the user. Comply therefore with adequate precautions for purification.

### 10. Maintenance

In principle, this device is maintenance-free. If desired, the housing of the device can be cleaned when switched off using a damp cloth and non-aggressive cleaning solutions.

Depending on the measuring medium, however, the diaphragm may be polluted or coated with deposit. If the medium is known for such tendencies, the user has to set appropriate cleaning intervals. After placing the device out of service correctly, the diaphragm can usually be cleaned carefully with a non-aggressive cleaning solution and a soft brush or sponge. If the diaphragm is calcified, it is recommended to send the device to BD SENSORS for decalcification. Please read therefore the chapter "Repair" below.

! An incorrect cleaning can cause irreparable damages on the diaphragm. Never use spiky objects or pressured air for cleaning the diaphragm.

### 11. Service/Repair

#### 11.1 Recalibration

During the life-time of a transmitter, the value of offset and span may shift. As a consequence, a deviating signal value in reference to the nominal pressure range starting point or end point may be transmitted. If one of these two phenomena occurs after prolonged use, a recalibration is recommended to ensure furthermore high accuracy.

#### 11.2 Return

Before every return of your device, whether for recalibration, decalcification, modifications or repair, it is necessary to contact us to ensure a fast handling of your request. Please inform us by sending an email to: sale@bdsensors.cz. Include the number of devices sent and request a RMA. Then clean the device and pack it shatterproof before send it to BD SENSORS indicating the RMA.

### 12. Disposal

The device must be disposed according to the European Directives 2012/19/EU and 16/2022 coll. (on waste electrical and electronic equipment). Waste of electrical and electronic equipment may not be disposed by domestic refuse!



⚠ WARNING! Depending on the measuring medium, deposit on the device may cause danger for the user and the environment. Comply with adequate precautions for purification and dispose of it properly.

### 13. Warranty conditions

The warranty conditions are subject to the legal warranty period of 24 months from the date of delivery. In case of improper use, modifications of or damages to the device, we do not accept warranty claims. Damaged diaphragms will also not be accepted. Furthermore, defects due to normal wear are not subject to warranty services.

### 14. Declaration of conformity / CE

The delivered device fulfils all legal requirements. The applied directives, harmonised standards and documents are listed in the EC declaration of conformity, which is available online at www.bdsensors.com. Additionally, the operational safety is confirmed by the CE sign on the manufacturing label.